

Drop Down
Ladder RacksClamp & Lock
Ladder Racks

Crossbar Racks



Cargo Racks

	Passenger Side	Driver Side	Passenger Side	Driver Side	2 Bars	3rd Bar	(5 Crossbars)
GM							
CHEVY EXPRESS, GMC SAVANA	4092L*	40963	4082L*	4081L	40823	40824	80160*
Factory Preassembled Double Drop Down Rack	4095L*						
*Required Mount Kit	409CD		408CC				4089C
FORD							
TRANSIT LOW ROOF	4092L*	40963	4082L*	4081L	40821	40822	80160*
Factory Preassembled Double Drop Down Rack	4095L*						
*Required Mount Kit	409TD		408TC				4089T
TRANSIT MID/HIGH ROOF	4099H*	40913					
*Required Mount Kit	409TD						
TRANSIT CONNECT	40933	40943	4080L	4081L	40821	40822	80100*
*Required Mount Kit							4089D
MERCEDES							
METRIS - 126" WB only	4092L*	40963	4082L*	4081L	40821	40822	
Factory Preassembled Double Drop Down Rack	4095L*						
*Required Mount Kit	4081M		4081M				
SPRINTER STANDARD ROOF	4097M*	40983			40821	40822	80160*
*Required Mount Kit	4081S						4089T
SPRINTER HIGH ROOF	4099H*	40913					
*Required Mount Kit	4081S						
NISSAN							
NV LOW ROOF	4092L*	40963	4082L*	4081L	40821	40822	80160*
Factory Preassembled Double Drop Down Rack	4095L*						
*Required Mount Kit	409ND		409ND				4089T
NV HIGH ROOF	4099H*	40913					
*Required Mount Kit	409ND						
NV200	40933	40943	4080L	4081L	40821	40822	80100*
*Mount Kit Included							4089D
RAM							
PROMASTER LOW ROOF	4097M*	40983			40821*	40822	80160*
*Required Mount Kit	4081P				40918		4089P
PROMASTER HIGH/SUPER HIGH ROOF	4099H*	40913					
*Required Mount Kit	4081P						
PROMASTER CITY	40933	40943	4080L	4081L	40821	40822	80100*
*Required Mount Kit							4089D

Available at Contractor's Solutions: www.Contractors-Solutions.net

Drop Down
Ladder RacksClamp & Lock
Ladder Racks

Crossbar Racks



Cargo Racks

Passenger
Side Driver SidePassenger
Side Driver Side

2 Bars 3rd Bar

(5 Crossbars)

GM

CHEVY EXPRESS, GMC SAVANAFactory Preassembled Double Drop
Down Rack

*Required Mount Kit

4A93L* 4A96L

4A95L*

409CD

4A82L*

4A81L

408CC

4A823

4A824

8016A*

4089C

FORD

TRANSIT LOW ROOFFactory Preassembled Double Drop
Down Rack

*Required Mount Kit

4A93L* 4A96L

4A95L*

409TD

4A82L*

4A81L

408TC

4A821

4A822

8016A*

4089T

TRANSIT MID/HIGH ROOFFactory Preassembled Double Drop
Down Rack

*Required Mount Kit

4A99H* 4A91H

4A95H*

409TD

TRANSIT CONNECTFactory Preassembled Double Drop
Down Rack

*Required Mount Kit

4A97L 4A98L

4A95C

4A80L

4A81L

4A821

4A822

8010A*

4089D

MERCEDES

METRIS - 126" WB and 135" WBFactory Preassembled Double Drop
Down Rack

4A97L 4A98L

4A95C

4A80L

4A81L

4A821

4A822

SPRINTER STANDARD ROOFFactory Preassembled Double Drop
Down Rack

*Required Mount Kit

4A93M* 4A96M

4A95M*

4081S

4A821

4A822

8016A*

4089T

SPRINTER HIGH ROOFFactory Preassembled Double Drop
Down Rack

*Required Mount Kit

4A99H* 4A91H

4A95H*

4081S

NISSAN

NV LOW ROOFFactory Preassembled-Assembled
Double Drop Down Rack

*Required Mount Kit

4A93L* 4A96L

4A95L*

409ND

4A82L*

4A81L

409ND

4A821

4A822

4089A*

4089T

NV HIGH ROOFFactory Preassembled Double Drop
Down Rack

*Required Mount Kit

4A99H* 4A91H

4A95H*

409ND

NV200Factory Preassembled Double Drop
Down Rack

*Required Mount Kit

4A97L 4A98L

4A95C

4A80L

4A81L

4A821

4A822

8010A*

4089D

PROMASTER STANDARD ROOFFactory Preassembled Double Drop
Down Rack

*Required Mount Kit

4A93M* 4A96M

4A95M*

4081P

4A821*

4A822

8016A*

40918

4089P

PROMASTER HIGH/SUPER HIGH ROOFFactory Preassembled Double Drop
Down Rack

*Required Mount Kit

4A99H* 4A91H

4A95H*

4081P

PROMASTER CITYFactory Preassembled Double Drop
Down Rack

*Required Mount Kit

4A97L 4A98L

4A95C

4A80L

4A81L

4A821

4A822

8010A*

4089D

v3.20 071422